



#1 Open Mattress ReNew completely so that air valves and passage chambers are exposed. “Creases” that may have occurred inside the carton will become flattened out by opening and gently stretching out the product at this time.

#2 Lie down on your mattress as you normally do to identify the areas of the mattress that are sagging and no longer providing you with adequate support. This will serve as a reminder as to where your mattress needs support.

#3 Using the air pump which has been included for your convenience add air to any of the 12 inflation chambers based on what you observed in step #2. Pump air into the valve opening for each corresponding air chamber. Seal each air valve after pumping with the fitted valve cover and make sure the seal is tight and secure.


Note: The number of chambers receiving air will depend on the size of your mattress and the degree of sagging in the mattress.

TWIN size mattresses may need air in chambers 4,5,6,7,8,9 (A).

FULL size mattresses may need air in chambers 4,5,6,7,8,9, and possibly in 2,3,10,11 (A or B).

QUEEN size mattresses may need air in chambers 2,3,4,5,6,7,8,9,10,11 and possibly 1 & 12 (B or C).

KING size mattresses may require air in all chambers (C).



#4 Using very limited amounts of air, pump the valves so the corresponding chambers slowly begin to inflate. Pump air into Mattress ReNew with the product fully open so that all air passages are accessible (C). Each inflation chamber will likely require a different degree of air pressure depending on the specific needs of your mattress. Typically, several pumps of air will make a significant difference and inflation chambers will never need to be filled completely. Some chambers may require no air at all.

Do Not Over-Inflate!

#5 Carefully lift your mattress away from its underlying box spring, foundation, or solid base before putting Mattress ReNew in place. **Always exercise caution when lifting your mattress; it is recommended that you have the assistance of another person when lifting heavy objects such as mattresses.** Then, position Mattress ReNew so that the inflated chambers will meet the mattress above it in the appropriate areas. At this time if you have a smaller sized mattress such as a Twin or Full you may wish to tuck the unused sections underneath Mattress ReNew along the air passage “fold” lines (as seen in Diagrams A and B). **Now, put your mattress back in place, once again exercising caution in lifting.**

#6 Lie down on your mattress. **You will immediately feel the difference!** If Mattress ReNew has been over-inflated or under-inflated simply repeat the steps above and adjust the amount of air you have pumped into the air chambers. It will take just a few minutes for you to achieve the desired “feel” in your mattress.